

#### **Specifications**

Name	Smart Lamp Holder
Input	AC 90-250V 50/60Hz
Output	AC 90-250V 50/60Hz
Operating Systems	Android 5.0 & iOS 10) or higher
Frequency Standard	WiFi(802.11 b/g/n 2.4GHz)
Dimension	E27
Color	White
Material	PC V0

## Installation instructions Installing lamp



 Device's default power-on state is "ON".If you want to set it to"OFF", you need to manually select the power-on state to "OFF" in eWeLink

#### Please check the following before using the device:

- · Your phone has been connected to a 2.4G WiFi. Your phone system version needs to be Android 5.0/iOS 10 or higher.
- · Your phone must be able to access the APP store and download the APP.
- . If your router has set Mac address filtering, please enter the router settings to turn off it.



## Pairing with eWeLink APP

- Ownload APP
- Onnect your phone to 2.4GHz WiFi and turn on Bluetooth
- 3 Long press pairing button for more than 5 seconds until blus LED indicator blinks twice quickly and keeps on once to enter
- Open eWelink APP,tap add device in the top right corner of the screen



Select the wifi connected to the phone, confirm the relevant information, and click



6 After searching for the device, click • on the right to add it




## Compatible Pairing Mode

If you fail to enter Quick Pairing Mode (Touch), please try "Compatible Pairing Mode "to pair.


- 1 Long press Pairing button for 5s until the WiFi LED indicator changes in a cycle oftwo short flashes and one long flash and release. Long press Pairing button for 5s again until the WiFi LED indicator flashes quickly. Then, the device entersCompatible Pairing Mode
- 2 Tap "+" and select " Compatible Pairing Mode on APP.Select Wi-Fi SSID with ITEAD-\*\*\*\*\*\*
  and enter the password 12345678, and thengo back to eWeLink APP and tap "Next". Be patient until pairing completes.

#### Pairing with RM2.4G remote control













Note:If you need to delete the RM2.4G remote control enter the added interface and delete it

#### Features

This device is WiFi smart switch. Use your smart phone in Turn devices on or off in your home anywhere, set timer on/off, Share with your family to control and so on.

































# 智能灯座

#### 产品参数

产品名称 智能灯座 输入电压 AC 90-250V 50/60Hz	
输入电压 AC 90-250V 50/60Hz	
输出电压 AC 90-250V 50/60Hz	
支持平台 Android 5.0 & iOS 10) or higher	
通信频率 WiFi(802.11 b/g/n 2.4GHz)	
螺口类型 E27	
产品颜色 White	
产品材料 PC V0	

#### 安装说明


## 装上灯座



① 该设备默认通电反应未"开启",如接电器设备时 需手动在APP中修改通电反应为"关闭"。

# 使用该设备前请检查以下事项:

- 您的智能手机已连接上一个能上网的2.4G
- 事机系统版本需要是安卓5.0以上,或者iOS 10.0以上版本。
- 手机必须能访问APP商店并下载APP。
- 如果您的无疑路由器设置了Mac地址过滤,请 先进入路由器后台关闭Mac过滤功能。



#### 设备与易微联APP的配对方法

- 下载易微联APP
- 季机连接2.4GHz的WiFi,打开手机蓝牙
- 3 长按配对按键5秒以上,指示灯快闪两 次,长亮一次,进入配网模式。
- 4 打开APP、点击右上角 ↔ 选择 "添加设备"



⑤ 选择手机连接的2.4GHz-WiFi, 确 认相关信息无误,点击"下一步"



6 搜索到可添加的设备后,点击右边 的 🖸 进行添加。




### 兼容模式(AP)

如果使用快速添加模式配网失败,请使用"兼容 模式(AP)"进行配对。

- 4 长按配对按键5秒直到设备指示灯呈"两短 一长闪烁"状态,松开按键。再次长按配对 按键5秒直到设备指示灯呈"快闪"状态,此 时设备进入兼容模式。
- ② 在app界面,点击"+",选择"兼容模式"。先 把移动设备连接 FWi-Fi账号为: ITEAD-\*\*\*\*\*\*,密码为:12345678,然后回到"易微 联"app,点击"下一步",等待配对完成。

#### 设备与RM2.4G遥控器配对



1 点开已添加的设备,点击右上角设置图标





@ ···

2 选择"轻智能遥控器"。

← living room lamps

2 Select "eWeLink Remote"

Create group

WeChat control

eWeLink Remote Scene


eWeLink Remote

← 客厅灯

LAN control

Device Settings











注:如需删除RM2.4G遥控器,进入添加遥控器 界面.删除即可。

## 产品特点

本设备是一款WiFi智能开关。用您的智能手机在 任何地方打开或关闭家里的设备,设置定时开/关, 分享给您的家人控制等等。











APP控制 智能定时 情景联动 语音控制 上电设置