User Manual



WIFI Smart Switch

Specifications

Name	WIFI Smart Switch
Input	AC 90V-250V 50/60Hz
Output	AC 90V-250V 50/60Hz
Operating Systems	Android 5.0 & iOS 10) or higher
Frequency Standard	WiFi(802.11 b/g/n 2.4GHz)
Current	10A
Material	ABS

Installation instructions

Ceiling lamp wiring instruction



Make sure correct wiring before powering the device on.

Please check the following before using the device

- Your phone has been connected to a 2.4G WiFi.
- Your phone system version needs to be Android 5.0/iOS 10 or higher.
- Your phone must be able to access the APP store and download the APP.
- If your router has set Mac address filtering, please enter the router settings to turn off it.



Pairing with eWeLink APP

1. Download APP
2. Connect your phone to 2.4GHz WiFi and turn on Bluetooth.
3. Long press pairing button for more than 5 seconds until blus LED indicator blinks twice quickly and keeps on once to enter pairing mode.
4. Open eWelink APP,tap + add device in the top right corner of the screen

5. Select the wifi connected to the phone, confirm the relevant information, and click Next

6. After searching for the device, click + on the right to add it



Compatible Pairing Mode

If you fail to enter Quick Pairing Mode (Touch), please try "Compatible Pairing Mode "to pair.

1. Long press Pairing button for 5s until the WiFi LED indicator changes in a cycle oftwo short flashes and one long flash and release. Long press Pairing button for 5s again until the WiFi LED indicator flashes quickly. Then, the device entersCompatible Pairing Mode.
2. Tap "+" and select " Compatible Pairing Mode " on APP.Select Wi-Fi SSID with ITEAD-****** and enter the password 12345678, and thengo back to eWeLink APP and tap "Next". Be patient until pairing completes.

Pairing with RM2.4G remote control



1. Open the added device and click the settings icon in the upper right corner.





2. Select "eWeLink Remote"



2. Follow the prompts for the next step.The LED indicator "flashes once again"means the pairing is successful.





Note:If you need to delete the RM2.4G remote control,enter the added interface and delete it.

Features

This device is WiFi smart switch. Use your smart phone inTurn devices on or off in your home anywhere, set timer on/off,Share with your family to control and so on.

产品使用说明书



WIFI 智能开关

产品参数

产品名称	WIFI 智能开关
输入电压	AC 90V-250V 50/60Hz
输出电压	AC 90V-250V 50/60Hz
支持平台	(Android 4.1 & iOS 9.0)或者更高版本
通信频率	WiFi(802.11 b/g/n 2.4GHz)
最大电流	10A
外壳材料	ABS

安装说明

吸顶灯接线示意



确保零火线接入无误后，再进行上电。

使用该设备前请检查以下事项：

- 您的智能手机已链接上一个能上网的2.4G WiFi;
- 手机系统版本需要是安卓5.0以上,或者IOS 10.0以上版本;
- 手机必须能够访问APP商店并下载APP;
- 如果您的无线路由器设置了Mac地址过滤,请先进入路由器后台关闭Mac过滤功能。



设备与易微联APP的配对方法

1. 下载易微联APP
2. 手机连接2.4GHz的WiFi,打开手机蓝牙;
3. 长按配对按键5秒以上，指示灯快闪两次，长亮一次，进入配网模式。
4. 打开APP，点击右上角 +，选择"添加设备"；

5. 选择手机连接的2.4GHz-WiFi，确认相关信息无误，点击"下一步"；

6. 搜索到可添加的设备后，点击右边的 + 进行添加。

兼容模式(AP)

如果使用快速添加模式配网失败,请使用"兼容模式(AP)"进行配对。

1. 长按配对按键5秒直到设备指示灯呈"两短一长闪烁"状态,松开按键。再次长按配对按键5秒直到设备指示灯呈"快闪"状态,此时设备进入兼容模式。
2. 在app界面,点击"+",选择"兼容模式"。先把移动设备连接上Wi-Fi账号为：ITEAD-******,密码为:12345678,然后回到"易微联"app,点击"下一步",等待配对完成。

设备与RM2.4G遥控器配对



1. 点开已添加的设备,点击右上角设置图标。



2. 选择"轻智能遥控器"。

2. 根据提示进行下一步操作,遥控器指示灯闪烁一下,即配对成功。



注:如需删除RM2.4G遥控器,进入添加遥控器界面,删除即可。

产品特点

本设备是一款WiFi智能开关。用您的智能手机在任何地方打开或关闭家里的设备，设置定时开/关,分享给您的家人控制等等。